



1966 Martin D18 neck reset and K&K pick up install